

Retrofitting new palm fronds into existing trunks



- 1) Remove all the old fronds
- 2) Slide new frond mounting cap over existing trunk
- 3) Screw three set screws (included) through the frond mounting cap holes and on into the trunk
- 4) Slide the new larger fronds (9 each) into every other slot of the mounting cap. Make sure the steel splint on the fronds points outward and away from the trunk.
- 5 Grab a frond, and pull (bend) every other one down until it is almost parallel with the top of the mounting cap.
- 6 Pull the remaining fronds down to about 45 degrees
- 7 Randomly insert the remaining (3) smaller fronds into any of the nine empty slots
- 8 Adjust the fronds to suit. Some like the fronds up higher, some like the fronds pulled down lower.
- 9 If in a high wind area, the cavity of the mounting cap can be filled with expanding foam (Great Stuff)

This is what your finished fronds should look like. By staggering the bending of every other frond, your palm trees will have a very nice, natural and full look.

