

Custom concrete pads to support (2) 12' Island Breeze palms for a hammock.

Each concrete pad needs to be 36" L x 24" W x 18" Deep.

After the holes are dug, (6) rebar stakes 1/2" x 24" need to be driven down into each hole leaving 4"-6" of the rebar exposed so that when the concrete is poured the concrete "grabs" the rebar stakes and "anchors" the concrete pad securely to the ground.

The trees are extremely heavy and with the addition of hammock occupant weight it is very important that the concrete foundation be very secure for safety.

Below is a diagram for placement of the concrete pads.

Palm Tree Hammock Footer Engineering

